

Kit 1053



MAZDA 626, 4-dr Sedan, 98-02

MAZDA 626, 5-dr Hatchback, 98-02


MAZDA Capella, 4-dr Sedan, 98-02

FORD Telstar, 4-dr Sedan, 98-02



480R
754



480












750




THULE[®]
SWEDEN

ISO 11154-E







3




754



750



1




2




X

MAZDA 626, 4-dr Sedan, 98-02	35,5
MAZDA 626, 5-dr Hatchback, 98-02	36
MAZDA Capella, 4-dr Sedan, 98-02	35,5
FORD Telstar, 4-dr Sedan, 98-02	35,5

1



2



Y

MAZDA 626, 4-dr Sedan, 98-02	33
MAZDA 626, 5-dr Hatchback, 98-02	33
MAZDA Capella, 4-dr Sedan, 98-02	33
FORD Telstar, 4-dr Sedan, 98-02	33




480R



480

1



2




X inch

X mm

MAZDA 626, 4-dr Sedan, 98-02	39 5/8"	1006 mm
MAZDA 626, 5-dr Hatchback, 98-02	39 3/4"	1011 mm
MAZDA Capella, 4-dr Sedan, 98-02	39 5/8"	1006 mm
FORD Telstar, 4-dr Sedan, 98-02	39 5/8"	1006 mm

1



2



Y inch

Y mm

MAZDA 626, 4-dr Sedan, 98-02	38 5/8"	981 mm
MAZDA 626, 5-dr Hatchback, 98-02	38 5/8"	981 mm
MAZDA Capella, 4-dr Sedan, 98-02	38 5/8"	981 mm
FORD Telstar, 4-dr Sedan, 98-02	38 5/8"	981 mm












4

MAZDA 626, 4-dr Sedan, 98-02


MAZDA 626, 5-dr Hatchback, 98-02

MAZDA Capella, 4-dr Sedan, 98-02



FORD Telstar, 4-dr Sedan, 98-02



5



	X mm	Y mm	X inch	Y inch
MAZDA 626, 4-dr Sedan, 98-02	230 mm	700 mm	9"	27 1/2"
MAZDA 626, 5-dr Hatchback, 98-02	230 mm	700 mm	9"	27 1/2"
MAZDA Capella, 4-dr Sedan, 98-02	230 mm	700 mm	9"	27 1/2"
FORD Telstar, 4-dr Sedan, 98-02	230 mm	700 mm	9"	27 1/2"



GB/US Tighten alternately

D Die Schrauben abwechselnd anziehen

F Serrer alternativement chaque côté

NL Afwisselend aan de linker- en de rechterkant aandraaien

I Alternare il serraggio delle viti

E Apretar alternativamente

PT Aperte alternadamente

S Dra åt växelvis

FIN Kierrä vuorotellen

EST Pinguldage vaheldumisi

LAT Pievelciet pamišus

LIT Užsukinėkite pakaitomis

PL Śruby dokręcaj naprzemiennie

RU Затягивайте попеременно

CZ Pokręťte bagážníka dokręcaj dokręcaj naprzemiennie.

SK Doťahujte striedavo

SLO Privijajte izmenično.

HR Naizmjenično zategnite

HU Egymástól függetlenül szorítandó

GR Σφιγγετε εναλλάξ

TR Dönüşümlü sıkın

中文 交替拧紧

한국어 번갈아 가며 조이십시오.

日本語 交互に締め付けてください。

ไทย ชันในแบบสลับ






6





480R/754



480



750




i




1




2




i




1




2




i








1



2





THULE®
SWEDEN

**ONE
KEY
SYSTEM**

		(x4)
		(x6)
		(x8)
NA		(x10)
EUR		(x12)
ASIA		