


SPECIFICATION SHEET RSS136

VEHICLE BRAND	MAZDA
VEHICLE TYPE	6 – 4DR & 5DR
YEAR MODEL	6/02 ON
LOAD RATING	40KG



SPECIAL FITTING TIPS

The Mazda 6 has 4 set fixing points to which the crossbars mount to. Slide covers in direction of arrows, remove covers which will expose nutsert. Note that there are front and rear crossbars. Place pad over nutsert hole. Seat crossbars into pads in correct position and tighten all bolts. Do Not Over Tighten Bolts. See picture below.

SPECIFICATIONS:

Front Bar – 85.5cm Rear Bar – 84.0cm

Manufactured By Rhino-Rack 3 Pike St Rydalmere, NSW 2116, Australia (Ph) 02 9638 4744 (Fax) 02 9638 4822

