





Kit 1007

RENAULT Laguna I, 5-dr Hatchback, 94-00



480R
754



480



750



THULE[®]
SWEDEN

ISO 11154-E

The diagram illustrates the assembly process. It features a 'THULE' box on the left, a plus sign in the center, and a 'Kit XXXX' box on the right. The 'Kit XXXX' box contains a table of contents with icons for various components: a bag, a bag with a strap, a bag with a strap and a small box, a bag with a strap and a small box, a bag with a strap and a small box, and a bag with a strap and a small box. To the right of the 'Kit XXXX' box is a large warning triangle with an exclamation mark. Below the 'Kit XXXX' box is a silhouette of a person reading a document.











					
					
					
					
					
					
					
					
					



Diagram illustrating the assembly of the base plate. The base plate is shown with four L-shaped feet (labeled 30) and four long L-shaped feet (labeled 04) attached. A separate view shows the four long L-shaped feet (labeled 04) and the four L-shaped feet (labeled 30) separately. A small icon of a box is shown in the top left corner.



3



1



2





RENAULT Laguna I, 5-dr Hatchback, 94-00

X

33

1



2



RENAULT Laguna I, 5-dr Hatchback, 94-00

Y

30,5




480R




480

1



2



RENAULT Laguna I, 5-dr Hatchback, 94-00


X inch

X mm


38 5/8"

981 mm

1



2



RENAULT Laguna I, 5-dr Hatchback, 94-00

Y inch














Y mm

37 5/8"






956 mm

4

RENAULT Laguna I, 5-dr Hatchback, 94-00



5



GB/US Tighten alternately

D Die Schrauben abwechselnd anziehen

F Serrer alternativement chaque côté

NL Afwisselend aan de linker- en de rechterkant aandraaien

I Alternare il serraggio delle viti

E Apretar alternativamente

PT Aperte alternadamente

S Dra åt växelvis

FIN Kierrä vuorotellen

EST Pinguldage vaheldumisi

LAT Pievelciet pamišus

LIT Užsukinėkite pakaitomis

PL Śruby dokręcaj naprzemiennie

RU Затягивайте попеременно

CZ Pokręťte багаžníka dokręcaj dokręcaj naprzemiennie.

SK Doťahujte striedavo

SLO Privijajte izmenično.

HR Naizmjenično zategnite

HU Egymástól függetlenül szorítandó

GR Σφιγγετε εναλλάξ

TR Dönüşümlü sıkın

中文 交替拧紧

한국어 번갈아 가며 조이십시오.

日本語 交互に締め付けてください。

ไทย ชันในแบบสลับ






6





480R/754



480



750




i




1




2




i



1




2




i








1



2





THULE®
SWEDEN

**ONE
KEY
SYSTEM**

544 (x4)

596 (x6)

588 (x8)

NA 510 (x10)

EUR 452 (x12)

ASIA