



Kit 1028



SAAB 900, 3-dr Hatchback, 94-97

SAAB 9-3, 3-dr Hatchback, 98-03



**480R
754**



480








750




THULE[®]
SWEDEN



ISO 11154-E



3





754




750



1



2




SAAB 900, 3-dr Hatchback, 94-97
SAAB 9-3, 3-dr Hatchback, 98-03


X

23,5

1



2



SAAB 900, 3-dr Hatchback, 94-97
SAAB 9-3, 3-dr Hatchback, 98-03

Y

20




480R




480

1



2



SAAB 900, 3-dr Hatchback, 94-97
SAAB 9-3, 3-dr Hatchback, 98-03

X inch

X mm


34 ⁷/₈ "

886 mm


34 ⁷/₈ "

886 mm

1



2



SAAB 900, 3-dr Hatchback, 94-97
SAAB 9-3, 3-dr Hatchback, 98-03

Y inch

Y mm

33 ¹/₂ "

851 mm














33 ¹/₂ "

851 mm


4

SAAB 900, 3-dr Hatchback, 94-97





SAAB 9-3, 3-dr Hatchback, 98-03



5




	X mm	Y mm	X inch	Y inch
SAAB 900, 3-dr Hatchback, 94-97	180 mm	730 mm	7 1/8"	28 3/4"
SAAB 9-3, 3-dr Hatchback, 98-03	180 mm	730 mm	7 1/8"	28 3/4"



GB/US Tighten alternately
D Die Schrauben abwechselnd anziehen
F Serrer alternativement chaque côté
NL Afwisselend aan de linker- en de rechterkant aandraaien
I Alternare il serraggio delle viti
E Apretar alternativamente
PT Aperte alternadamente
S Dra åt växelvis
FIN Kierrä vuorotellen
EST Pinguldage vaheldumisi
LAT Pievelciēt pamišus
LIT Užsukinėkite pakaitomis
PL Śruby dokręcaj naprzemiennie
RU Затягивайте попеременно

CZ Pokrétla багажníka dokręcaj dokręcaj naprzemiennie.
SK Doťahujte striedavo
SLO Privijajte izmenično.
HR Naizmenično zategnite
HU Egymástól függetlenül szorítandó
GR Σφιγγετε εναλλάξ
TR Dönüşümlü sıkın
中文 交替拧紧
한국어 번갈아 가며 조이십시오.
日本語 交互に締め付けてください。
ไทย ขันในแบบสลับ






6





480R/754



480



750




i




1




2




i




1




2




i








1



2





THULE®
SWEDEN

**ONE
KEY
SYSTEM**

		(x4)
		(x6)
		(x8)
NA		(x10)
EUR		(x12)
ASIA		