

Kit 1060




HYUNDAI Coupé, 2-dr Coupé, 97-00

HYUNDAI Tiburon, 2-dr Coupé, 97-00 / *97-01

SUBARU Legacy, 4-dr Sedan, 99-03 / *00-04

SUBARU Liberty, 4-dr Sedan, 99-03

*North America








THULE®
SWEDEN


ISO 11154-E

The diagram illustrates the importance of instructions. It features two boxes: one labeled 'THULE' with a warning symbol and a plus sign, and another labeled 'Kit XXXX' with a warning symbol and the word 'instructions'. A person is shown reading a manual, emphasizing the need to follow instructions.


					
					
					
					
					
					
					
					
					



3





754



750



1




2



	X
HYUNDAI Coupé, 2-dr Coupé, 97-00	30,5
HYUNDAI Tiburon, 2-dr Coupé, 97-00 / *97-01	30,5
SUBARU Legacy, 4-dr Sedan, 99-03 / *00-04	40
SUBARU Liberty, 4-dr Sedan, 99-03	40

1



2



	Y
HYUNDAI Coupé, 2-dr Coupé, 97-00	25,5
HYUNDAI Tiburon, 2-dr Coupé, 97-00 / *97-01	25,5
SUBARU Legacy, 4-dr Sedan, 99-03 / *00-04	38
SUBARU Liberty, 4-dr Sedan, 99-03	38




480R




480

1




2




	X inch	X mm
HYUNDAI Coupé, 2-dr Coupé, 97-00	37 ⁵ / ₈ "	956 mm
HYUNDAI Tiburon, 2-dr Coupé, 97-00 / *97-01	37 ⁵ / ₈ "	956 mm
SUBARU Legacy, 4-dr Sedan, 99-03 / *00-04	41 ³ / ₈ "	1051 mm
SUBARU Liberty, 4-dr Sedan, 99-03	41 ³ / ₈ "	1051 mm

1



2





	Y inch	Y mm
HYUNDAI Coupé, 2-dr Coupé, 97-00	35 ⁵ / ₈ "	906 mm
HYUNDAI Tiburon, 2-dr Coupé, 97-00 / *97-01	35 ⁵ / ₈ "	906 mm
SUBARU Legacy, 4-dr Sedan, 99-03 / *00-04	40 ⁵ / ₈ "	1031 mm
SUBARU Liberty, 4-dr Sedan, 99-03	40 ⁵ / ₈ "	1031 mm












4

HYUNDAI Coupé, 2-dr Coupé, 97-00
HYUNDAI Tiburon, 2-dr Coupé, 97-00 / *97-01


SRA




SUBARU Legacy, 4-dr Sedan, 99-03 / *00-04
SUBARU Liberty, 4-dr Sedan, 99-03





5



	X mm	Y mm	X inch	Y inch
HYUNDAI Coupé, 2-dr Coupé, 97-00	130 mm	650 mm	5 1/8"	25 5/8"
HYUNDAI Tiburon, 2-dr Coupé, 97-00 / *97-01	130 mm	650 mm	5 1/8"	25 5/8"
SUBARU Legacy, 4-dr Sedan, 99-03 / *00-04	220 mm	630 mm	8 5/8"	24 3/4"
SUBARU Liberty, 4-dr Sedan, 99-03	220 mm	630 mm	8 5/8"	24 3/4"



HYUNDAI Coupé, 2-dr Coupé, 97-00
HYUNDAI Tiburon, 2-dr Coupé, 97-00 / *97-01



GB/US Tighten alternately
D Die Schrauben abwechselnd anziehen
F Serrer alternativement chaque côté
NL Afwisselend aan de linker- en de rechterkant aandraaien
I Alternare il serraggio delle viti
E Serrare alternativamente
PT Aperte alternadamente
S Dra åt växelvis

FIN Kierrä vuorotellen
EST Pinguldage vaheldumisi
LAT Pievelciēt pamišus
LIT Užsukinkite pakaitomis
PL Śruby dokręcaj naprzemiennie
RU Затягивайте попеременно
CZ Pokręťte багаžníka dokręcaj dokręcaj naprzemiennie.
SK Dofahujte striedavo
SLO Privijajte izmenično.
HR Naizmjenično zategnite
HU Egy mástól függetlenül szorítandó
GR Σφίγγετε εναλλάξ
TR Dönüşümlü sıkın
中文 交替拧紧
한국어 번갈아 가며 조이십시오.
日本語 交互に締め付けてください。
ไทย ชั้้นในแบบสลับ






6





480R/754



480



750




i




1




2




i




1




2




i








1



2





THULE®
SWEDEN

**ONE
KEY
SYSTEM**

		(x4)
		(x6)
		(x8)
NA		(x10)
EUR		(x12)
ASIA		