



Kit 1072


MERCEDES A-Class, 5-dr Hatchback, 98-00

MERCEDES A-Class (W168), 5-dr Hatchback, 01-04



**480R
754**



480








750




Max.
50 kg

Max.
110 lbs


Kit



3




754




750



1




2



X

MERCEDES A-Class, 5-dr Hatchback, 98-00	32
MERCEDES A-Class (W168), 5-dr Hatchback, 01-04	32,5

1



2



Y

MERCEDES A-Class, 5-dr Hatchback, 98-00	25,5
MERCEDES A-Class (W168), 5-dr Hatchback, 01-04	26




480R



480

1




2




X inch X mm

MERCEDES A-Class, 5-dr Hatchback, 98-00	38 1/4"	971 mm
MERCEDES A-Class (W168), 5-dr Hatchback, 01-04	38 3/8"	976 mm

1



2
















Y inch Y mm

MERCEDES A-Class, 5-dr Hatchback, 98-00	35 5/8"	906 mm
MERCEDES A-Class (W168), 5-dr Hatchback, 01-04	35 7/8"	911 mm


4

MERCEDES A-Class, 5-dr Hatchback, 98-00



MERCEDES A-Class (W168), 5-dr Hatchback, 01-04



5



	X mm	Y mm	X inch	Y inch
MERCEDES A-Class, 5-dr Hatchback, 98-00	130 mm	650 mm	5 1/8"	25 5/8"
MERCEDES A-Class (W168), 5-dr Hatchback, 01-04	130 mm	700 mm	5 1/8"	27 1/2"



GB/US Tighten alternately

D Die Schrauben abwechselnd anziehen

F Serrer alternativement chaque côté

NL Afwisselend aan de linker- en de rechterkant aandraaien

I Alternare il serraggio delle viti

E Apretar alternativamente

PT Aperte alternadamente

S Dra åt växelvis

FIN Kierrä vuorotellen

EST Pinguldage vaheldumisi

LAT Pievelciet pamišus

LIT Užsukinėkite pakaitomis

PL Śruby dokręcaj naprzemiennie

RU Затягивайте попеременно

CZ Pokręťte багаžníka dokręcaj dokręcaj naprzemiennie.

SK Doťahujte striedavo

SLO Privijajte izmenično.

HR Naizmjenično zategnite

HU Egymástól függetlenül szorítandó

GR Σφιγγετε εναλλάξ

TR Dönüşümlü sıkın

中文 交替拧紧

한국어 번갈아 가며 조이십시오.

日本語 交互に締め付けてください。

ไทย ขันในแบบสลับ






6





480R/754



480



750




i




1




2




i




1




2




i








1



2





THULE®
SWEDEN

**ONE
KEY
SYSTEM**

		(x4)
		(x6)
		(x8)
NA		(x10)
EUR		(x12)
ASIA		