



Kit 1075



HONDA Civic Shuttle, 5-dr MPV, 95-02

HONDA Odyssey, 5-dr MPV, 95-99



**480R
754**








480




750






3




754




750



1



2




HONDA Civic Shuttle, 5-dr MPV, 95-02	X
HONDA Odyssey, 5-dr MPV, 95-99	37

X

37

1



2



HONDA Civic Shuttle, 5-dr MPV, 95-02	Y
HONDA Odyssey, 5-dr MPV, 95-99	34

Y

34




480R



480

1




2



	X inch	X mm
HONDA Civic Shuttle, 5-dr MPV, 95-02	40 1/4"	1021 mm
HONDA Odyssey, 5-dr MPV, 95-99	40 1/4"	1021 mm

1



2



	Y inch	Y mm
HONDA Civic Shuttle, 5-dr MPV, 95-02	39"	991 mm
HONDA Odyssey, 5-dr MPV, 95-99	39"	991 mm

Y inch

Y mm

39"

991 mm














39"

991 mm


4

HONDA Civic Shuttle, 5-dr MPV, 95-02




HONDA Odyssey, 5-dr MPV, 95-99



5



	X mm	Y mm	X inch	Y inch
HONDA Civic Shuttle, 5-dr MPV, 95-02	570 mm	700 mm	22 1/2"	27 1/2"
HONDA Odyssey, 5-dr MPV, 95-99	570 mm	700 mm	22 1/2"	27 1/2"



GB/US Tighten alternately

D Die Schrauben abwechselnd anziehen

F Serrer alternativement chaque côté

NL Afwisselend aan de linker- en de rechterkant aandraaien

I Alternare il serraggio delle viti

E Apretar alternativamente

PT Aperte alternadamente

S Dra åt växelvis

FIN Kierrä vuorotellen

EST Pinguldage vaheldumisi

LAT Pievelciet pamišus

LIT Užsukinėkite pakaitomis

PL Śruby dokręcaj naprzemiennie

RU Затягивайте попеременно

CZ Pokręťte багаžníka dokręcaj dokręcaj naprzemiennie.

SK Doťahujte striedavo

SLO Privijajte izmenično.

HR Naizmjenično zategnite

HU Egymástól függetlenül szorítandó

GR Σφίγγετε εναλλάξ

TR Dönüşümlü sıkın

中文 交替拧紧

한국어 번갈아 가며 조이십시오.

日本語 交互に締め付けてください。

ไทย ชันในแบบสลับ






6





480R/754



480




750




i




1




2




i




1




2




i








1



2





THULE®
SWEDEN

**ONE
KEY
SYSTEM**

		(x4)
		(x6)
		(x8)
NA		(x10)
EUR		(x12)
ASIA		