




Kit 1079

MITSUBISHI Lancer, 4-dr Sedan, 96-99



**480R
754**








480






750





Kit



3



1




2



MITSUBISHI Lancer, 4-dr Sedan, 96-99

X
25,5

1



2



MITSUBISHI Lancer, 4-dr Sedan, 96-99

Y
24,5




480R




480

1



2




MITSUBISHI Lancer, 4-dr Sedan, 96-99


X inch
35 5/8"

X mm
906 mm

1



2










MITSUBISHI Lancer, 4-dr Sedan, 96-99

Y inch
35 1/4"


Y mm
896 mm

4




MITSUBISHI Lancer, 4-dr Sedan, 96-99



5



	X mm	Y mm	X inch	Y inch
MITSUBISHI Lancer, 4-dr Sedan, 96-99	230 mm	650 mm	9 "	25 5/8 "



GB/US Tighten alternately

D Die Schrauben abwechselnd anziehen

F Serrer alternativement chaque côté

NL Afwisselend aan de linker- en de rechterkant aandraaien

I Alternare il serraggio delle viti

E Apertar alternativamente

PT Aperte alternadamente

S Dra åt växelvis

FIN Kierrä vuorotellen

EST Pinguldage vaheldumisi

LAT Pievelciēt pamišus

LIT Užsukinėkite pakaitomis

PL Śruby dokręcaj naprzemiennie

RU Затягивайте попеременно

CZ Pokręťta bagażníka dokręcaj dokręcaj naprzemiennie.

SK Doťahujte striedavo

SLO Privijajte izmenično.

HR Naizmjenično zategnite

HU Egymástól fűggetlenül szorítandó

GR Σφιγγετε εναλλάξ

TR Dönüşümlü sıkın


中文 交替拧紧

한국어 번갈아 가며 조이십시오.

日本語 交互に締め付けてください。

ไทย ชันในแบบสลับ






6





480R/754



480



750




i




1




2




i




1




2




i








1



2





THULE®
SWEDEN

**ONE
KEY
SYSTEM**

		(x4)
		(x6)
		(x8)
NA		(x10)
EUR		(x12)
ASIA		