



Thule Rapid System Kit 1088

> Instructions

TOYOTA RAV4, 3-dr SUV, 94-99 / *95-00

TOYOTA RAV4, 5-dr SUV, 94-99 / *96-00

*North America

The diagram is divided into four main sections:

- Top Left:** An information icon (i) and a warning triangle (⚠) are shown. An arrow points to a person reading a manual. Next to them are two manuals: Manual B (Thule Rapid System Kit 1088) and Manual A (Thule Rapid System 754). An arrow points from Manual B to Manual A, which shows a roof rack being installed on a car. A pencil and a notepad are also shown.
- Top Right:** A weight calculation diagram. It shows a bag labeled "xx kg / xx lbs" plus a roof rack labeled "7 kg / 15,4 lbs" and two screws labeled "3 kg / 6,6 lbs". Below this, an equals sign points to a box containing "Max. 75 kg" and "Max. 165 lbs".
- Bottom Left:** A warning triangle (⚠) is shown. Next to it are three manuals: Manual A (Thule Rapid System 754), Manual B (Thule Rapid System Kit 1088), and a weight table. An arrow points to a person reading a manual.
- Bottom Right:** A warning triangle (⚠) is shown. Next to it is a speedometer diagram. The speedometer has a warning triangle in the red zone. The speedometer scale shows 40 km/h (25 Mph), 80 km/h (50 Mph), and 130 km/h (80 Mph). Arrows point to the roof rack on a car, indicating that the weight limit is exceeded at speeds above 80 km/h.

ISO 11154-E

141088


C.20150501
519-1088-02

Bring your life

thule.com



07 x4



176 x4





x1



x1

1


	X (scale)	X (mm)	X (inch)
TOYOTA RAV4 , 3-dr SUV, 94-99 / *95-00	26,5	916	36 ¹ / ₈
TOYOTA RAV4 , 5-dr SUV, 94-99 / *96-00	26,5	916	36 ¹ / ₈




	Y (scale)	Y (mm)	Y (inch)
TOYOTA RAV4 , 3-dr SUV, 94-99 / *95-00	25,5	906	35 ⁵ / ₈
TOYOTA RAV4 , 5-dr SUV, 94-99 / *96-00	25,5	906	35 ⁵ / ₈

2



SRA




TOYOTA RAV4, 3-dr SUV, 94-99 / *95-00




TOYOTA RAV4, 5-dr SUV, 94-99 / *96-00



3



	W (mm)	Z (mm)	Y (mm)	W (inch)	Z (inch)	Y (inch)
TOYOTA RAV4, 3-dr SUV, 94-99 / *95-00	300	700	350	11 3/4	27 1/2	13 3/4



	W (mm)	Z (mm)	W (inch)	Z (inch)
TOYOTA RAV4, 5-dr SUV, 94-99 / *96-00	300	700	11 3/4	27 1/2

