






Kit 1164

NISSAN AD, 5-dr Van, 00–

TOYOTA RAV 4, 3-dr SUV, 00–03, 04–

TOYOTA RAV 4, 5-dr SUV, 00–03, 04–

TOYOTA Regius, 5-dr Van, 00–



THULE[®]
SWEDEN

ISO 11154-E

NISSAN AD

xx kg / xx lbs + 7 kg / 15,4 lbs = **Max. 50kg/110 lbs**

TOYOTA RAV 4

xx kg / xx lbs + 7 kg / 15,4 lbs = **Max. 60kg/132 lbs**




TOYOTA Regius

xx kg / xx lbs + 7 kg / 15,4 lbs = **Max. 75kg/165 lbs**


 





THULE Kit XXXX  


480R/754 x1 x4 x4




  

480 x1 x4 x4


750 x1 x4 x4




				
 x2	 x2	 x2	 x2	 x2
 x2		 x4	 x2	
 x2		 x4		
 x4				



 **309** x4

 **02** x4

 **22** x4

 **x1**

Kit

1




480R/754



480



750



2



480R/754















480






750



+




3



1




2



	X
NISSAN AD, 5-dr Van, 00–	14
TOYOTA RAV 4, 3-dr SUV, 00-03, 04–	22
TOYOTA RAV 4, 5-dr SUV, 00-03, 04–	22
TOYOTA Regius, 5-dr Van, 00–	32

1



2



	Y
NISSAN AD, 5-dr Van, 00–	11,5
TOYOTA RAV 4, 3-dr SUV, 00-03, 04–	18
TOYOTA RAV 4, 5-dr SUV, 00-03, 04–	18
TOYOTA Regius, 5-dr Van, 00–	32




480R




480

1




2




	X inch	X mm
NISSAN AD, 5-dr Van, 00–	31 1/8"	791 mm
TOYOTA RAV 4, 3-dr SUV, 00-03, 04–	34 1/4"	871 mm
TOYOTA RAV 4, 5-dr SUV, 00-03, 04–	34 1/4"	871 mm
TOYOTA Regius, 5-dr Van, 00–	38 1/4"	971 mm

1




2



	Y inch	Y mm
NISSAN AD, 5-dr Van, 00–	30 1/8"	766 mm
TOYOTA RAV 4, 3-dr SUV, 00-03, 04–	32 3/4"	831 mm
TOYOTA RAV 4, 5-dr SUV, 00-03, 04–	32 3/4"	831 mm
TOYOTA Regius, 5-dr Van, 00–	38 1/4"	971 mm

4







NISSAN AD, 5-dr Van, 00–




TOYOTA RAV 4, 3-dr SUV, 00-03, 04–

TOYOTA RAV 4, 5-dr SUV, 00-03, 04–



TOYOTA Regius, 5-dr Van, 00–






5



	X mm	Y mm	X inch	Y inch
NISSAN AD, 5-dr Van, 00–	285 mm	835 mm	11 1/4"	32 7/8"



TOYOTA RAV 4, 3-dr SUV, 00-03, 04–
TOYOTA RAV 4, 5-dr SUV, 00-03, 04–
TOYOTA Regius, 5-dr Van, 00–



GB/US Tighten alternately
D Die Schrauben abwechselnd anziehen
F Serrer alternativement chaque côté
NL Afwisselend aan de linker- en de rechterkant aandraaien
I Alternare il serraggio delle viti
E Apretar alternativamente
PT Aperte alternadamente
S Dra åt växelvis
FIN Kierrä vuorotellen
EST Pinguldage vaheldumisi
LAT Pievelciēt pamišus
LIT Užsukinėkite pakaitomis
PL Śruby dokręcaj naprzemiennie
RU Затягивайте попеременно

CZ Pokręťta bagażníka dokręcaj naprzemiennie.
SK Doťahujte striedavo
SLO Privijajte izmenično.
HR Naizmjениčno zategnite
HU Egymástól függetlenül szorítandó
GR Σφιγγείτε εναλλάξ
TR Dönüşümlü sıkın

中文 交替拧紧
한국어 번갈아 가며 조이십시오.
日本語 交互に締め付けてください。
ไทย ชั้้นโนแบบสลับ






6





480R/754



480



750




i




1




2




i



1




2




i








1



2





THULE®
SWEDEN

**ONE
KEY
SYSTEM**

		(x4)
		(x6)
		(x8)
NA		(x10)
EUR		(x12)
ASIA		