





Kit 1174

TOYOTA Celica, 3-dr Coupé, 00-05



480R
754



480



750




 **xx kg**
xx lbs

 **7 kg / 15,4 lbs**

 **3 kg / 6,6 lbs**

Max. 50 kg
Max. 110 lbs























 **x1**


 **x4**

 **x4**

 **x4**

480R/754

 **x1**


 **x4**

 **x4**

 **x4**


480




 **x1**

 **x4**


 **x4**

750




				
 x2	 x2	 x2	 x2	 x2
 x2		 x2	 x2	
 x2		 x4		
 x4		 x4		










347 **x4**





16 **x4**

 **x1**



Kit



3



1



2




TOYOTA Celica, 3-dr Coupé, 00-05

X

33

1



2



TOYOTA Celica, 3-dr Coupé, 00-05

Y

31




480R



480

1



2



X inch


X mm

TOYOTA Celica, 3-dr Coupé, 00-05

38 5/8"

981 mm

1



2



Y inch

Y mm

TOYOTA Celica, 3-dr Coupé, 00-05








37 7/8"

961 mm


4

TOYOTA Celica, 3-dr Coupé, 00-05





SRA



5




	X mm	Y mm	X inch	Y inch
TOYOTA Celica, 3-dr Coupé, 00-05	80 mm	695 mm	3 1/8"	27 3/8"



GB/US	Tighten alternately
D	Die Schrauben abwechselnd anziehen
F	Serrer alternativement chaque côté
NL	Afwisselend aan de linker- en de rechterkant aandraaien
I	Alternare il serraggio delle viti
E	Apretar alternativamente
PT	Aperte alternadamente
S	Dra åt växelvis
FIN	Kierrä vuorotellen
EST	Pinguldage vaheldumisi
LAT	Pievelciēt pamišus
LIT	Užsukinėkite pakaitomis
PL	Śruby dokręcaj naprzemiennie
RU	Затягивайте попеременно

CZ	Pokrétla bagazníka dokręcaj dokręcaj naprzemiennie.
SK	Dofahujte striedavo.
SLO	Privijajte izmenično.
HR	Naizmjenično zategnite
HU	Egymástól függetlenül szorítandó
GR	Σφιγγετε εναλλάξ
TR	Dönüşümlü sıkın
中文	交替拧紧
한국어	번갈아 가며 조이십시오.
日本語	交互に締め付けてください。
ไทย	ขันในแบบสลับ






6





480R/754



480



750




i




1




2




i



1




2




i








1



2





THULE®
SWEDEN

**ONE
KEY
SYSTEM**

		(x4)
		(x6)
		(x8)
NA		(x10)
EUR		(x12)
ASIA		