

Kit 1192



CHRYSLER Neon, 4-dr Sedan, 00-04

DODGE Neon, 4-dr Sedan, 00-04 / *00-05



PLYMOUTH Neon, 4-dr Sedan, 00-04 / *00-01

*North America



**480R
754**



480












750




THULE[®]
SWEDEN

ISO 11154-E







1


2

	X
CHRYSLER Neon, 4-dr Sedan, 00-04	20
DODGE Neon, 4-dr Sedan, 00-04 / *00-05	20
PLYMOUTH Neon, 4-dr Sedan, 00-04 / *00-01	20

1

2

	Y
CHRYSLER Neon, 4-dr Sedan, 00-04	16
DODGE Neon, 4-dr Sedan, 00-04 / *00-05	16
PLYMOUTH Neon, 4-dr Sedan, 00-04 / *00-01	16



1

2

	X inch	X mm
CHRYSLER Neon, 4-dr Sedan, 00-04	33 1/2"	851 mm
DODGE Neon, 4-dr Sedan, 00-04 / *00-05	33 1/2"	851 mm
PLYMOUTH Neon, 4-dr Sedan, 00-04 / *00-01	33 1/2"	851 mm

1

2













	Y inch	Y mm
CHRYSLER Neon, 4-dr Sedan, 00-04	31 7/8"	811 mm
DODGE Neon, 4-dr Sedan, 00-04 / *00-05	31 7/8"	811 mm
PLYMOUTH Neon, 4-dr Sedan, 00-04 / *00-01	31 7/8"	811 mm

4


CHRYSLER Neon, 4-dr Sedan, 00-04

DODGE Neon, 4-dr Sedan, 00-04 / *00-05







PLYMOUTH Neon, 4-dr Sedan, 00-04 / *00-01



5



	X mm	Y mm	X inch	Y inch
CHRYSLER Neon , 4-dr Sedan, 00-04	210 mm	650 mm	8 1/4"	25 5/8"
DODGE Neon , 4-dr Sedan, 00-04 / *00-05	210 mm	650 mm	8 1/4"	25 5/8"
PLYMOUTH Neon , 4-dr Sedan, 00-04 / *00-01	210 mm	650 mm	8 1/4"	25 5/8"



GB/US Tighten alternately

D Die Schrauben abwechselnd anziehen

F Serrer alternativement chaque côté

NL Afwisselend aan de linker- en de rechterkant aandraaien

I Alternare il serraggio delle viti

E Serrare alternativamente

PT Aperte alternadamente

S Dra åt växelvis

FIN Kierrä vuorotellen

EST Pinguldage vaheldumisi

LAT Pievelciēt pamišus

LIT Užsukinėkite pakaitomis

PL Śruby dokręcaj naprzemiennie

RU Затягивайте попеременно

CZ Pokręťta bagazníka dokręcaj dokręcaj naprzemiennie.

SK Doťahujte striedavo

SLO Privijajte izmenično.

HR Naizmjenično zategnite

HU Egymástól függetlenül szorítandó

GR Σφίγγετε εναλλάξ

TR Dönüşümlü sıkın


中文 交替拧紧

한국어 번갈아 가며 조이십시오.

日本語 交互に締め付けてください。

ไทย ขันในแบบสลับ






6





480R/754




480



750




i




1




2




i




1




2




i








1



2





THULE®
SWEDEN

**ONE
KEY
SYSTEM**

		(x4)
		(x6)
		(x8)
NA		(x10)
EUR		(x12)
ASIA		(x12)