



Kit 1281


HYUNDAI Getz, 3-dr Hatchback, 02-04, 05-

HYUNDAI Getz, 5-dr Hatchback, 02-04, 05-



**480R
754**



480



750



THULE[®]
SWEDEN

ISO 11154-E

HYUNDAI Getz, 3-dr Hatchback, 02-04, 05-


 $xx \text{ kg}$
 $xx \text{ lbs}$
 $+$

 $7 \text{ kg} / 15,4 \text{ lbs}$
 $+$


 $3 \text{ kg} / 6,6 \text{ lbs}$
 $=$
Max.
50kg/110 lbs

HYUNDAI Getz, 3-dr Hatchback, 02-04, 05-


 $xx \text{ kg}$
 $xx \text{ lbs}$
 $+$

 $7 \text{ kg} / 15,4 \text{ lbs}$
 $=$
Max.
75kg/165 lbs







80 km/h
 50 Mph
 130 km/h
 80 Mph
 40 km/h
 25 Mph
 km/h
 Mph



 $+$

Kit XXXX







x1

x4


x4

x4

480R/754


x1

x4


x4

x4




480


x1

x4

x4


750



				
 x2	 x2	 x2	 x2	 x2
 x2		 x2	 x2	
 x2		 x4		
 x4		 x4		









108
x4



07
x4


x1


Kit



3




754



750



1




2



X

HYUNDAI Getz, 3-dr Hatchback, 02-04, 05-	32,5
HYUNDAI Getz, 5-dr Hatchback, 02-04, 05-	32,5

1



2



Y

HYUNDAI Getz, 3-dr Hatchback, 02-04, 05-	32,5
HYUNDAI Getz, 5-dr Hatchback, 02-04, 05-	32,5




480R




480

1




2




X inch X mm

HYUNDAI Getz, 3-dr Hatchback, 02-04, 05-	38 ³ / ₈ "	976 mm
HYUNDAI Getz, 5-dr Hatchback, 02-04, 05-	38 ³ / ₈ "	976 mm

1



2





Y inch Y mm

HYUNDAI Getz, 3-dr Hatchback, 02-04, 05-	38 ³ / ₈ "	976 mm
HYUNDAI Getz, 5-dr Hatchback, 02-04, 05-	38 ³ / ₈ "	976 mm







4

HYUNDAI Getz, 3-dr Hatchback, 02-04, 05-


SRA




HYUNDAI Getz, 5-dr Hatchback, 02-04, 05-






5



	X mm	Y mm	X inch	Y inch
HYUNDAI Getz, 3-dr Hatchback, 02-04, 05-	310 mm	690 mm	12 1/4"	27 1/8"
HYUNDAI Getz, 5-dr Hatchback, 02-04, 05-	330 mm	700 mm	13"	27 1/2"



HYUNDAI Getz, 3-dr Hatchback, 02-04, 05-




GB/US Tighten alternately
D Die Schrauben abwechselnd anziehen
F Serrer alternativement chaque côté
NL Afwisselend aan de linker- en de rechterkant aandraaien
I Alternare il serraggio delle viti
E Apretar alternativamente
PT Aperte alternadamente
S Dra åt växelvis
FIN Kierrä vuorotellen
EST Pinguldage vaheldumisi
LAT Pievelciēt pamišus
LIT Užsukinėkite pakaitomis
PL Śruby dokręcaj naprzemiennie
RU Затягивайте попеременно

CZ Pokręťla багаžníka dokręcaj dokręcaj naprzemiennie.
SK Doťahujte striedavo
SLO Privijajte izmenično.
HR Naizmjenično zategnite
HU Egymástól függetlenül szorítandó
GR Σφιγίγγετε εναλλάξ
TR Dönüşümlü sıkın

中文 交替拧紧
한국어 번갈아 가며 조이십시오.
日本語 交互に締め付けてください。
ไทย ชันในแบบสลับ



6






480R/754








480



750





THULE®
SWEDEN

**ONE
KEY
SYSTEM**

544 (x4)

596 (x6)

588 (x8)

NA 510 (x10)

EUR 452 (x12)

ASIA