






# Kit 1335

HONDA Odyssey, 5-dr Estate, 03-08



**THULE**<sup>®</sup>  
SWEDEN

ISO 11154-E

480R/754

x1

x4

x4

480

x1

x4

x4

750

x1






x4

x4




|  |  |  |  |  |  |
|--|--|--|--|--|--|
|  |  |  |  |  |  |
|  |  |  |  |  |  |
|  |  |  |  |  |  |
|  |  |  |  |  |  |
|  |  |  |  |  |  |
|  |  |  |  |  |  |
|  |  |  |  |  |  |
|  |  |  |  |  |  |
|  |  |  |  |  |  |

Parts list for step 10:



- 2x 616
- 2x 617
- 1x 170
- 1x 4-way connector



3



1




2



HONDA Odyssey, 5-dr Estate, 03-08

X  
48

1



2



HONDA Odyssey, 5-dr Estate, 03-08

Y  
44




480R




480

1



2




HONDA Odyssey, 5-dr Estate, 03-08


X inch X mm

44 1/2" 1131 mm

1



2
















HONDA Odyssey, 5-dr Estate, 03-08

Y inch Y mm


43" 1091 mm

# 4




HONDA Odyssey, 5-dr Estate, 03-08



5



|                                   | X mm   | Y mm   | X inch  | Y inch  |
|-----------------------------------|--------|--------|---------|---------|
| HONDA Odyssey, 5-dr Estate, 03-08 | 520 mm | 700 mm | 20 1/2" | 27 1/2" |



**GB/US** Tighten alternately

**D** Die Schrauben abwechselnd anziehen

**F** Serrer alternativement chaque côté

**NL** Afwisselend aan de linker- en de rechterkant aandraaien

**I** Alternare il serraggio delle viti

**E** Apertar alternativamente

**PT** Aperte alternadamente

**S** Dra åt växelvis

**FIN** Kierrä vuorotellen

**EST** Pinguldage vaheldumisi

**LAT** Pievelciet pamišus

**LIT** Užsukinėkite pakaitomis

**PL** Śruby dokręcaj naprzemiennie

**RU** Затягивайте попеременно

**CZ** Pokręťta bagażníka dokręcaj dokręcaj naprzemiennie.

**SK** Doťahujte striedavo

**SLO** Privijajte izmenično.

**HR** Naizmjenično zategnite

**HU** Egymástól fűggetlenül szorítandó

**GR** Σφιγγετε εναλλάξ

**TR** Dönüşümlü sıkın






**中文** 交替拧紧






**한국어** 번갈아 가며 조이십시오.

**日本語** 交互に締め付けてください。

**ไทย** ชันในแบบสลับ

6





**THULE®**  
SWEDEN

**ONE  
KEY  
SYSTEM**

544 (x4)

596 (x6)

588 (x8)

NA 510 (x10)

EUR 452 (x12)

ASIA