




Kit 1348

TOYOTA Hilux, 2-dr Single Cab, 05–
 TOYOTA Hilux, 2-dr X-tra Cab, 05–
 TOYOTA Vigo, 2-dr Single Cab, 04–
 TOYOTA Vigo, 2-dr X-tra Cab, 04–



TOYOTA Hilux, 2-dr Single Cab, 05-
TOYOTA Vigo, 2-dr Single Cab, 04-

 xx kg
xx lbs

+

 3,5 kg / xx lbs

=

Max.
25kg/55 lbs

TOYOTA Hilux, 2-dr X-tra Cab, 05-
TOYOTA Vigo, 2-dr X-tra Cab, 04-

 xx kg
xx lbs

+

 7 kg / 15,4 lbs

=

Max.
50kg/110 lbs







80 km/h
50 Mph

130 km/h
80 Mph

40 km/h
25 Mph


km/h
Mph

THULE




+

Kit XXXX











 x1

 x4


 x4

 x4

 x4

480R/754

 x1


 x4

 x4

 x4

480


 x1



 x4

 x4

 x4

750



				
 x2	 x2	 x2	 x2	 x2
 x2		 x2	 x2	
 x2		 x4		
 x4		 x4		








 **653** x2

 **657** x2


 **07** x4

 x1


Kit



3




754



750



1




2



	X
TOYOTA Hilux, 2-dr Single Cab, 05–	43
TOYOTA Hilux, 2-dr X-tra Cab, 05–	43
TOYOTA Vigo, 2-dr Single Cab, 04–	43
TOYOTA Vigo, 2-dr X-tra Cab, 04–	43

1



2



	Y
TOYOTA Hilux, 2-dr Single Cab, 05–	-
TOYOTA Hilux, 2-dr X-tra Cab, 05–	42,5
TOYOTA Vigo, 2-dr Single Cab, 04–	-
TOYOTA Vigo, 2-dr X-tra Cab, 04–	42,5




480R



480

1




2



	X inch	X mm
TOYOTA Hilux, 2-dr Single Cab, 05–	42 1/2"	1081 mm
TOYOTA Hilux, 2-dr X-tra Cab, 05–	42 1/2"	1081 mm
TOYOTA Vigo, 2-dr Single Cab, 04–	42 1/2"	1081 mm
TOYOTA Vigo, 2-dr X-tra Cab, 04–	42 1/2"	1081 mm

1




2










	Y inch	Y mm
TOYOTA Hilux, 2-dr Single Cab, 05–	-	-
TOYOTA Hilux, 2-dr X-tra Cab, 05–	42 3/8"	1076 mm
TOYOTA Vigo, 2-dr Single Cab, 04–	-	-
TOYOTA Vigo, 2-dr X-tra Cab, 04–	42 3/8"	1076 mm

4


TOYOTA Hilux, 2-dr Single Cab, 05–
TOYOTA Vigo, 2-dr Single Cab, 04–




TOYOTA Hilux, 2-dr X-tra Cab, 05–
TOYOTA Vigo, 2-dr X-tra Cab, 04–




5





	X mm	Y mm	X inch	Y inch
TOYOTA Hilux, 2-dr Single Cab, 05–	270 mm	–	10 ⁵ / ₈ "	–
TOYOTA Hilux, 2-dr X-tra Cab, 05–	270 mm	700 mm	10 ⁵ / ₈ "	27 ¹ / ₂ "
TOYOTA Vigo, 2-dr Single Cab, 04–	270 mm	–	10 ⁵ / ₈ "	–
TOYOTA Vigo, 2-dr X-tra Cab, 04–	270 mm	700 mm	10 ⁵ / ₈ "	27 ¹ / ₂ "



TOYOTA Hilux, 2-dr Single Cab, 05–
TOYOTA Vigo, 2-dr Single Cab, 04–




TOYOTA Hilux, 2-dr X-tra Cab, 05–
TOYOTA Vigo, 2-dr X-tra Cab, 04–



GB/US Tighten alternately
D Die Schrauben abwechselnd anziehen
F Serrer alternativement chaque côté
NL Afwisselend aan de linker- en de rechterkant aandraaien
I Alternare il serraggio delle viti
E Apretar alternativamente
PT Aperte alternadamente
S Dra åt växelvis
FIN Kierrä vuorotellen
EST Pinguldage vaheldumisi
LAT Pievelciēt pamišus
LIT Užsukinėkite pakaitomis
PL Śruby dokręcaj naprzemiennie
RU Затягивайте попеременно

CZ Pokręťte багажníka dokręcaj dokręcaj naprzemiennie.
SK Dotahujte striedavo
SLO Privijajte izmenično.
HR Naizmenično zategnite
HU Egymástól függetlenül szorítandó
GR Σφίγγετε εναλλάξ
TR Dönüşümlü sıkın
中文 交替拧紧
한국어 번갈아 가며 조이십시오.
日本語 交互に締め付けてください。
ไทย ขันในแบบสลับ



6






480R/754








480



750





THULE®
SWEDEN

**ONE
KEY
SYSTEM**

		(x4)
		(x6)
		(x8)
NA		(x10)
EUR		(x12)
ASIA		








www.thuleprofessional.com






info@thule.com
customer.service@thule.com



Thule Inc., 42 Silvermine Road, Seymour, Connecticut 06483, USA
 Thule Sweden AB, Box 69, 330 33 Hillerstorp, SWEDEN








GB/US
D
F
NL
I
PT
S
FIN
EST
LAT
LIT
PL
RU


Tighten alternately
Die Schrauben abwechselnd
anziehen
Serrer alternativement chaque côté
Aflosselend aan de linker- en de
rechtterkant aandraaien
Alternare il serraggio delle viti
Aperte alternativamente
Dra át káxelvis
Kierrä vuorotellen
Piguldīge vaihdumisi
Paveiciet pārmēsus
Uzskūņēkite pakārtomis
Śrubę dokręcaj naprzemiennie
Затягивайте попеременно

中文
한국어
日本語


Pokrepla bagaznika dokręcaj
SK
SLO
HR
HU
GR
TR
Zpřevyete evyadē
Dongyumūu sūkin
交替拧紧
편감아 가며 조이십시오.
交互に締め付けてください。
வழிவழியுறியு







TOYOTA Hilux, 2-dr Single Cab, 05-
TOYOTA Vigo, 2-dr Single Cab, 04-
TOYOTA Hilux, 2-dr X-tra Cab, 05-
TOYOTA Vigo, 2-dr X-tra Cab, 04-









TOYOTA Hilux, 2-dr Single Cab, 05-	270 mm	—	10 5/8"	—	27 1/2"
TOYOTA Hilux, 2-dr X-tra Cab, 05-	270 mm	700 mm	10 5/8"	10 5/8"	27 1/2"
TOYOTA Vigo, 2-dr Single Cab, 04-	270 mm	—	10 5/8"	—	—
TOYOTA Vigo, 2-dr X-tra Cab, 04-	270 mm	700 mm	10 5/8"	10 5/8"	27 1/2"












instructions

© 20090713: 503-1348

ISO 11154-E

PROFESSIONAL

THULE
SWEDEN®



- TOYOTA Hilux, 2-dr Single Cab, 05-
- TOYOTA Hilux, 2-dr X-tra Cab, 05-
- TOYOTA Vigo, 2-dr Single Cab, 04-
- TOYOTA Vigo, 2-dr X-tra Cab, 04-

Kit 1348