



Kit 1417

AUDI A3, 3-dr Hatchback, 03–



AUDI A3 Sportsback, 5-dr Hatchback, 04– / *06–

*North America



**480R
754**



480



750




THULE[®]
SWEDEN








ISO 11154-E

AUDI A3 Sportsback,
5-dr Hatchback, 04–


Max.
60 kg/132 lbs





+




573	x 2
-----	-----



◀ 07 x 2



686	x 4
-----	-----








◀ 149 x 2




x 1



Kit



3





754




750



1




2




	X
AUDI A3, 3-dr Hatchback, 03-	36
AUDI A3 Sportsback, 5-dr Hatchback, 04- / *06-	36


1



2



	Y
AUDI A3, 3-dr Hatchback, 03-	33
AUDI A3 Sportsback, 5-dr Hatchback, 04- / *06-	33




480R




480

1




2




	X inch	X mm
AUDI A3, 3-dr Hatchback, 03-	39 ³ / ₄ "	1011 mm
AUDI A3 Sportsback, 5-dr Hatchback, 04- / *06-	39 ³ / ₄ "	1011 mm

1




2










	Y inch	Y mm
AUDI A3, 3-dr Hatchback, 03-	38 ⁵ / ₈ "	981 mm
AUDI A3 Sportsback, 5-dr Hatchback, 04- / *06-	38 ⁵ / ₈ "	981 mm

4


AUDI A3, 3-dr Hatchback, 03–







AUDI A3 Sportsback, 5-dr Hatchback, 04– / *06–



5




	X mm	Y mm	X inch	Y inch
AUDI A3, 3-dr Hatchback, 03–	260 mm	700 mm	10 1/4"	27 1/2"
AUDI A3 Sportsback, 5-dr Hatchback, 04– / *06–	270 mm	700 mm	10 5/8"	27 1/2"



GB/US Tighten alternately
D Die Schrauben abwechselnd anziehen
F Serrer alternativement chaque côté
NL Afwisselend aan de linker- en de rechterkant aandraaien
I Alternare il serraggio delle viti
E Serrare alternativamente
PT Aperte alternadamente
S Dra åt växelvis
FIN Kierrä vuorotellen
EST Pinguldage vaheldumisi
LAT Pievelciēt pamišus
LIT Užsukinėkite pakaitomis
PL Śruby dokręcaj naprzemiennie
RU Затягивайте попеременно

CZ Pokrétla багаžníka dokręcaj dokręcaj naprzemiennie.
SK Dofahujte striedavo
SLO Privijajte izmenično.
HR Naizmjenično zategnite
HU Egymástól függetlenül szorítandó
GR Σφιγγείτε εναλλάξ
TR Dönüşümlü sıkın
中文 交替拧紧
한국어 번갈아 가며 조이십시오.
日本語 交互に締め付けてください。
ไทย ขันในแบบสลับ






6





480R/754



480



750




i




1




2




i



1




2




i








1



2





THULE
SWEDEN

**ONE
KEY
SYSTEM**

		544 (x4)
		596 (x6)
		588 (x8)
NA		510 (x10)
EUR		452 (x12)
ASIA		