



Kit 1432


Holden Commodore VE, 4-dr Sedan, 06–

Holden Commodore VE, 5-dr Estate, 08–



**480R
754**



480












750




THULE[®]
SWEDEN

ISO 11154-E







3





754




750



1




2




	X
Holden Commodore VE, 4-dr Sedan, 06–	43
Holden Commodore VE, 5-dr Estate, 08–	43

1



2



	Y
Holden Commodore VE, 4-dr Sedan, 06–	43
Holden Commodore VE, 5-dr Estate, 08–	40,5




480R



480

1




2



	X inch	X mm
Holden Commodore VE, 4-dr Sedan, 06–	42 1/2"	1081 mm
Holden Commodore VE, 5-dr Estate, 08–	42 1/2"	1081 mm

1















2




	Y inch	Y mm
Holden Commodore VE, 4-dr Sedan, 06–	42 1/2"	1081 mm
Holden Commodore VE, 5-dr Estate, 08–	41 5/8"	1056 mm

4




Holden Commodore VE, 4-dr Sedan, 06–
Holden Commodore VE, 5-dr Estate, 08–



5



	X mm	Y mm	X inch	Y inch
Holden Commodore VE, 4-dr Sedan, 06–	230 mm	720 mm	9"	28 ³ / ₈ "
Holden Commodore VE, 5-dr Estate, 08–	230 mm	720 mm	9"	28 ³ / ₈ "



GB/US Tighten alternately

D Die Schrauben abwechselnd anziehen

F Serrer alternativement chaque côté

NL Afwisselend aan de linker- en de rechterkant aandraaien

I Alternare il serraggio delle viti

E Apretar alternativamente

PT Aperte alternadamente

S Dra åt växelvis

FIN Kierrä vuorotellen

EST Pinguldage vaheldumisi

LAT Pielvelciet pamišus

LIT Užsukinėkite pakaitomis

PL Śruby dokręcaj naprzemiennie

RU Затягивайте попеременно

CZ Pokręťte багаžníka dokręcaj dokręcaj naprzemiennie.

SK Doťahujte striedavo

SLO Privijajte izmenično.

HR Naizmjenično zategnite

HU Egymástól függetlenül szorítandó

GR Σφίγγετε εναλλάξ

TR Dönüşümlü sıkın

中文 交替拧紧

한국어 번갈아 가며 조이십시오.

日本語 交互に締め付けてください。

ไทย ขันในแบบสลับ






6





480R/754



480




750




i




1




2




i



1




2




i








1



2





THULE®
SWEDEN

**ONE
KEY
SYSTEM**

		(x4)
		(x6)
		(x8)
NA		(x10)
EUR		(x12)
ASIA		