




# Kit 1628


NISSAN Elgrand, 5-dr MPV, 10-  
NISSAN Quest, 5-dr Mini Van, 11-



**754** Rapid System  
**480R** Rapid Traverse (North America)



**480** Traverse (North America)




**754 Rapid System**  
**480R Rapid Traverse (North America)**

**754 Rapid System**  
**480R Rapid Traverse (North America)**  
**480 Traverse (North America)**

**(North America)**



1






2






754 Rapid System  
480R Rapid Traverse  
(North America)



x4





x4





x4




480 Traverse  
(North America)




x4

**3****754** Rapid System


	X
<b>NISSAN Elgrand, 5-dr MPV, 10-</b>	<b>45</b>
<b>NISSAN Quest, 5-dr Mini Van, 11-</b>	<b>45</b>




	Y
<b>NISSAN Elgrand, 5-dr MPV, 10-</b>	<b>43,5</b>
<b>NISSAN Quest, 5-dr Mini Van, 11-</b>	<b>43,5</b>

**3****480R** Rapid Traverse**480** Traverse**(North America)**

	X inch	X mm
<b>NISSAN Elgrand, 5-dr MPV, 10-</b>	<b>43 <sup>3</sup>/<sub>8</sub> "</b>	<b>1101 mm</b>
<b>NISSAN Quest, 5-dr Mini Van, 11-</b>	<b>43 <sup>3</sup>/<sub>8</sub> "</b>	<b>1101 mm</b>





	Y inch	Y mm
<b>NISSAN Elgrand, 5-dr MPV, 10-</b>	<b>42 <sup>3</sup>/<sub>4</sub> "</b>	<b>1086 mm</b>
<b>NISSAN Quest, 5-dr Mini Van, 11-</b>	<b>42 <sup>3</sup>/<sub>4</sub> "</b>	<b>1086 mm</b>





**4**

# 5


NISSAN Elgrand, 5-dr MPV, 10-  
NISSAN Quest, 5-dr Mini Van, 11-



6



7



<b>GB/US</b>	Tighten alternately
<b>D</b>	Die Schrauben abwechselnd anziehen
<b>F</b>	Serrer alternativement chaque côté
<b>NL</b>	Afwisselend aan de linker- en de rechterkant aandraaien
<b>I</b>	Alternare il serraggio delle viti
<b>E</b>	Apretar alternativamente
<b>PT</b>	Aperte alternadamente
<b>S</b>	Dra åt växelvis
<b>FIN</b>	Kierrä vuorotellen
<b>EST</b>	Pinguldage vaheldumisi
<b>LAT</b>	Pielveiciet pamišus
<b>LIT</b>	Užsukinėkite pakaitomis
<b>PL</b>	Śruby dokręcaj naprzemiennie
<b>RU</b>	Затягивайте попеременно





<b>CZ</b>	Pokręřta багаžnika dokręcaj naprzemiennie.
<b>SK</b>	Dofahajte striedavo
<b>SLO</b>	Privijajte izmenično.
<b>HR</b>	Naizmjenočno zategnite
<b>HU</b>	Egy mástól függetlenül szorítandó
<b>GR</b>	Σφιγίγτες εναλλάξ
<b>TR</b>	Dönüşümlü sıkın

**中文** 交替拧紧



**한국어** 번갈아 가며 조이십시오.

**日本語** 交互に締め付けてください。

**ไทย** ช้้นในแบบสลับ





≈ 3 Nm





8




x1  
17 mm






**THULE**  
SWEDEN  
**ONE  
KEY  
SYSTEM**



		(x4)
		(x6)
		(x8)
NA		(x10)
EUR		(x12)
ASIA		



WW ▶ Thule Sweden AB, Box 69, 330 33 Hillerstorp, SWEDEN  
NA ▶ Thule Inc., 42 Silvermine Road, Seymour, Connecticut 06483, USA

info@thule.com  
customer.service@thule.com

www.thule.com