











RHINO-RACK

Aerodynamic & Heavy Duty Roof Rack Systems

WARNING!





RHINO-RACK

Aerodynamic & Heavy Duty Roof Rack Systems

SXBS24 - Rhino Sportz

Maximum load capacity 80kg (176lbs)

- Please refer to your vehicle manufacturers handbook for maximum roof load capacity.
- Any load transported on Roof Racks must be evenly distributed.
- Instructions are to remain with the vehicle.
- Do not attempt to fit the roof racks to your vehicle unless you fully read and understand the fitting instructions provided.
- Please direct any questions to the dealer from where the roof racks were purchased.

Recommendations:

It is essential that all bolt connections be checked after driving a short distance when you first install your crossbars. Bolt connections should be checked again at regular intervals (probably once a week is enough, depending on road conditions, usage, loads and distances travelled). You should also check the crossbars each time they are refitted. Make sure to fasten your load securely. Please ensure that all loads are evenly distributed and that the centre of gravity is kept as low as possible.

Crossbars must be removed when putting vehicle through an automatic car wash.

Use only non-stretch fastening ropes or straps.

Caution: The handling characteristics of the vehicle changes when you transport a load on the roof. For safety reasons we recommend you exercise extreme care when transporting wind-resistant loads. Special consideration must be taken into account when cornering and braking.

Off-road Load Rating:

When crossbars are to be used in off-road conditions, please build a safety factor of 1.5 into this load limit for off-road use, two crossbars = **53kg 116lbs**). Although the crossbars are tested and approved to AS1235-2000, Off-road conditions can be much more rigorous. However, increasing the number of crossbars does not increase the vehicles maximum permissible roof loading.

Note for Dealers and Fitters:

It is your responsibility to ensure instructions are given to the end user or client.

Rhino-Rack

3 Pike Street, Rydalmere,
NSW 2116, Australia.
(Ph) (02) 9638 4744
(Fax) (02) 9638 4822

Document No: R56

Prepared By: Craig Jones

Authorised By: Chris Murty

Issue No: 01

Issue Date: 31/10/2011


These instructions remain the property of Rhino-Rack Australia Pty. Ltd. and may not be used or changed for any other purpose than intended.






SXBS24

Parts List

Item	Component Name	Qty	Part No
1	Buffer strip	2	R011
2	Crossbar 1140mm	2	RRC036
3	Locking end cap	4	M076
4	Key	3	C192
5	Under bar strip	4	R034
6	SXB Leg	4	SUB0392
7	5mm security allen key	1	SECKEY-L
8	Fitting instruction	1	R56






Tools:





SXBS24



3 Gap on underside of crossbar can be increased in length if required. Use pliers to remove material.







SXBS24

6



7



8

