
Important:

Please read these instructions carefully prior to installation.

Please refer to your fitting instruction to ensure that the bike rack is installed in the correct locations.

Check the contents of kit before commencing fitment and report any discrepancies.

Place these instructions in the vehicle's glove box after installation is complete.



Important Information

Maximum carrying capacity: 15kg (33lbs) per bike. Max 4 Bikes. Totalling 60kg/ 130lbs.

Warning: Do not attempt to fit the bike carrier to your vehicle unless you fully understand this fitting instructions. Please direct any questions regarding fitting to the dealer from where the bike carrier was purchased. Use only non-stretch fastening ropes or straps.

Recommendations:

It is essential that all bolt connections be checked after driving a short distance when you first install your bike carrier. Bolt connections should be checked again at regular intervals (once a week is enough, depending on road conditions, usage, loads and distances travelled). You should also check the bike carrier each time it is re-fitted. Always make sure to fasten your load securely. Please also ensure that all loads are evenly distributed and that the centre of gravity is kept as low as possible. Bike carrier must be removed when putting vehicle through an automatic car wash.

In some states it may be against the law to obstruct clear view of lamps and registration plates. It is suggested that the Rhino-Rack Number Plate Holder (RBCA011) be purchased.

Caution: The handling characteristics of the vehicle changes when you transport a load on the roof or at the rear. For safety reasons we recommend you exercise extreme care when transporting wind-resistant loads. Special consideration must be taken into account when cornering and braking.

Note for Dealers and Fitters

It is your responsibility to ensure this fitting instruction is given to the end user or client Rhino-Rack

3 Pike Street, Rydalmere,

NSW 2116, Australia. Document No: R1061 Fit Time: 20min (Ph) (02) 9638 4744 Prepared By: Kayle Everett Issue No: 01

(Fax) (02) 9638 4822 Authorised By: Chris Murty Issue Date: 28/07/2016

These instructions remain the property of Rhino-Rack Australia Pty Ltd and may not be used or changed for any other purpose than intended.



General Parts List

Item	Component Name	Qty	Part No.
1	Cruiser Bike Carrier Body	1	RBC051
2	Rubber Strap	16	M867
3	8mm Allen Key	1	SP151
4a	M10 x 30mm Cap Screw	3	SP133
4b	M10 Spring Washer	3	SP234
5	1/2" Hitch Pin	1	SP149
6	M13 Spring Washer	1	SP235
7	L Bracket	2	SP236
8	L Bracket Bolt	1	SP237
9	R Clip	1	SP150
10	Metal Key	1	-
11	Anti Sway Cradle	1	SP238
12	Safety Strap 4m	1	SP239
13	Instruction	1	R1061

Tools Required:


1:8mm Allen Key (provided)


2: 6mm Allen Key (for 1-1/4" Receiver)

3: 19mm Socket Wrench


er) Wrend

Instructions







Insert the bike rack into the 2" or 1-1/4" Hitch Mount Receiver. Install the 1/2" Hitch Pin and tighten. Lock in place by fixing the R Clip into the end of the Hitch Pin.




Insert the Bike Rack into the Hitch Mount. Use a 19mm Socket Wrench to tighten.

















When the Carrier is not in use, Lift the Locking Cam on top of the Bike Carrier. This will unlock the Carrier Arms. Drop the Arms, there will be an audible 'click' when the Arms reach their intended position.



To avoid collision with the rear hatch or door of the vehicle, Lift the Locking Cam at the bottom of the Bike Carrier. The unit will drop 45 degrees allowing access to the vehicle. Return to an upright position before driving.

Note: Carrier may interfere with reverse sensors (dependent on their position), giving a false reading. The visibility of surroundings through reverse cameras may also be impacted. Be cautious when reversing.

